List of Common Commands

Command	Description	Details and Examples
*** + 5-digit panID + #	Pairing Command	Pair a player unit or secondary coach unit to the primary coach. Example: ***23412#
*#	Clear Screen	Clears the display
**1x#	Set Vibration	0 = Off, 1-9 = # of vibrations, Default = 2 Examples: **1# turns vibration on with 2 vibes, **13# sets vibration count to 3
**2x#	Set Timeout	0 = Off, 1-9 = # of seconds, Default = 5 Examples: **2# sets the display timer to 5 seconds, **27# sets the timer to 7 seconds
**401#	Place Secondary Coach Unit into Pairing Mode	Places secondary coach unit into listening mode for 60 seconds and displays the 5-digit panID on the screen.
**42x#	Keypad Sync	0 = Receive Info, 1 = Send Info Example: **420# prepares a secondary coach to receive a sync command from the primary coach
**471#	Clear/Reset Network	Sends a command to all network devices to reset and reboot. The devices will be ready for pairing. **Only available on versions 2.2.9 and later and must be entered twice to validate command.
**491#	Clear Coach Unit	Clears the coach unit and releases all pairing information. **Must be entered twice on versions 2.2.9 and later to validate the command.
**51#	Show PanID	Makes all units display their 5-digit PanID on the screen for ~3 seconds.
**66#	Sync Sign List to Individual Device from Coach Unit	After entering the command, you will be prompted to enter the 5-digit panID of the device that you want to sync the list to.
**901#	Reset Battery Values	Resets calculated battery values to default settings
Call or email for assistance	Re-Master Network	Promotes a secondary coach unit to the master unit.

GAME DAY SIGNALS

Simple. Fast. Secure.

Extended

Technical Guide

GameDaySignals.com

T100 Coach Unit

Reset Button (Located in Pinhole on Left Side) - A small paper clip can be used to reboot the unit

Used as the Enter key to send a sign or command

Used to enter a command or change a setting (Refer to the Command List)

XR15 Player Unit

Power Button - Hold to turn the unit on/off

When unit is on, you can press the button to cycle through menu options

Single Press = Last Sign Recall

Hold Button = Reset Unit (Factory Reset)

Reset Button (Located in Pinhole on Left Side) - A small paper clip can be used to reboot the unit

XR5 Player Unit

Reset Button (Located in Pinhole)

A small paper clip can be used to reboot the unit by pressing and releasing the button.

Holding the button for 7-8 seconds will factory reset the unit and prepare it to be paired to a coach unit.